Planned maintenance



- Can be set up against:
  - Individual assets (one job per asset)
  - Locations (one job per location including all assets in that location
  - Installations (one job per installation including all assets in that installation
  - Site
- Set up against calendar or usage
- Automatic or manual release of PPM jobs
- Option to include pre-agreed values
- Attached PPM documents released with PPM job (service manuals etc.)
- Calendar Scheduler to view upcoming PPM jobs by service/site/supplier etc.
- Manual release of PPM jobs from scheduler
- Manual change to automatic PPM job release dates
- Automatic release to suppliers by e-mail/sms/system
- Tracking/management of PPM jobs as previously described

Asset-Pro